

Condensation Pan Overflows

Your marine air conditioners condensation pan is overflowing.

Drain pan nipple on pan clogged. Clean nipple.

Drain hose clogged, misaligned or kinked. Fix and/or clear hose.

Air conditioner not properly elevated to drain water to drain pan nipple. Check unit mounting to insure water will flow to nipple.

If a Mermaid Condensator is being used, ensure that the filter is clean. If not, clean filter and check flow of water through Condensator. Refer to the Mermaid on-line Condensator instructions for further assistance.